

System operating instructions

- Always use water that has been treated using the Realice System.
- Always fill the ice resurfacer as close to the ice maintenance as possible.
- Always use water with a temperature of max. 20°C. Use trial and error to obtain the best results.
- Always lay a thin layer of water that is allowed to freeze before the next layer of water is added.
- Always use both Realice Base and Realice Hand when laying ice for the first time and for repairs and ice maintenance.
- Measure and adjust the temperature of the ice regularly. Using the Realice System, the temperature of the ice can generally be raised by 1-2°C.
- More information is available at www.realice.se
- **Congratulations**
- **Your ice has now been improved.**



24RIS55008-A